

Temp sender pre-airflow 9/62 - 10/64



Description

Temp sender pre-airflow 9/62 - 10/64
The auxillary gauges on cars cars built between 9/62 & 10/64 operate at 10 volts through the voltage stabilizer but cars built between 10/64 - 11/66 operate on 5 volts for the gauges.