



Bell housing gasket



**Description**

Bell housing gasket fit between the bell housing and the main gearbox